

Acrylit Installation Guide:

Cutting:

Panels can be cut using power or hand saws.

Saw blades should be fine-toothed carbide tipped or safety fabric reinforced abrasive disc. Face shields and appropriate safety equipment should be worn by all operators. Some typical installation details are shown at the left.

Drilling:

All panels should be pre-drilled not less than 1-1/2" from the panel end, and the holes drilled a minimum of 1/16" larger than the fastener diameter. Panels can be drilled singly or several at a time.

Fasteners:

When possible, fasteners should be installed at high points of the corrugation with spacing of 6" on center for intermediate purlins and siding applications.

Installation:

Under no circumstances should panels be allowed to support undistributed loads such as the weight of a human body. Use only approved roof ladders for installation.